

twilight

INSTRUMENTOS DE MEDICIÓN INDUSTRIAL

Durómetro Análogo con Indicador de Picos, Tipo A Modelo E2D, Asker-IMADA

IM-E2PA

www.twilight.mx


 / [twilightsadecv](#)

 / [twilightsadecv](#)

 / [twilightsadecv](#)




Durometer E2 Series



INSTRUCTION MANUAL

How the E2 durometer works

By pressing the indenter into a surface, the material resistance force and the indenter spring force balance, whereby the depth of the indenter is measured providing the hardness of the material on a scale of 100 points.




For example, if the indenter doesn't move into the body of the durometer, the measurement is zero. If the indenter moves all the way into the body of the durometer, the measurement is 100. Results vary depending on the depth the indenter moves into the body of the durometer. Therefore it is not consistent but increases linearly as it indents.

E2 durometers conform to both ASTM D2240 and ISO specifications.


How to use the E2 durometer

1. Place the sample material horizontally on a hard surface.
2. Hold the durometer between both hands over the material so that the indenter touches it.
3. Push down perpendicularly to the test material until the presser foot makes firm contact.
4. Take a reading.



With Optional Peak Indicator

1. Make sure the peak indicator is set to zero.
2. Place the sample test material horizontally on a hard surface.
3. Hold the durometer between both hands over the material so that the indenter touches it.
4. Push down perpendicularly to the test material until the presser foot makes firm contact.
5. Lift the durometer and read the result from the peak indicator.
6. Before taking another reading, reset the peak indicator to zero and repeat the process.



Several tests should be made on a given sample and the results averaged. When recording hardness results, the following should be noted:

1. The temperature and humidity at the time of the test.
2. The time interval (in seconds) that elapses after the presser foot makes firm contact and the reading is made.

How to improve measurement accuracy

The surface to be tested must be flat, clean and smooth. (The maximum allowable surface roughness is ± 0.001 "). The test piece size must be at least .75" x 1.75" and thicker than .25" (6mm). If the sample is thinner than .25" (6mm), several layers of the same material can be stacked on top of each other (do not glue layers together) making sure there is no air between the layers.

You may take measurements from samples that do not conform to the above requirements, but test results should be used only as a reference.

It is recommended that you select different locations on the sample for each measurement, at least .25" away from any previous measurement. Keep your measurements at least .5" from all edges.


Higher readings result when pressing the durometer down fast (more force) and lower ones when pressing down slowly. To ensure consistent measurements apply consistent force.

Also, measurements may vary slightly if read at different times after taking the measurement. For example, you may get a slightly different reading if you read the result immediately versus 30 seconds later. Therefore, it is recommended that this aspect of measuring be consistent.

It is recommended that readings less than 10 and above 90 be avoided.

If you are using a durometer after it has been stored for a while, press the indenter on a surface about 20 times before using it.

Eliminate speed and weight variables with a constant load stand. Available with pneumatic speed control and flexible coupling or standard weight model.



IMPORTANT

Avoid applying a shock load to the indenter.

When storing, avoid environments that are humid, dusty or oily.

Do not lubricate.

Keep the indenter clean and free of scratches.



Troubleshooting

Checkpoint	Solution
1 Is the indenter shape correct?	Use an optical projector to accurately check the shape and dimensions of the indenter.
2 Is the indicator needle firmly mounted on the axle?	Press the indenter on a very hard surface so the needle points to 100.
3 Is the indenter height correct?	Make sure the needle points to zero without any pressure on the indenter.
4 Is the durometer mechanism working properly?	Height gauge is sold separately. Use it to make sure the durometer corresponds to the appropriate number (2, 50, 100 points).
5 Is the indenter pressure correct?	Apply accurate force and make sure the durometer indicates the specific hardness.

LIMITED WARRANTY

ONE-YEAR LIMITED WARRANTY AND LIMITATION OF LIABILITY: Hoto Instruments, for itself and its related companies warrants that all Hoto Instruments products sold, except for those specific products identified below, will be free of defects in materials and workmanship for a period of one (1) year from date of delivery to end-user. The foregoing one (1) year warranty shall not be extended or changed by Hoto Instruments furnishing any replacements, additions, attachments, accessories or repairs to the products subsequent to the date of delivery or acceptance. The foregoing warranty is the sole and exclusive warranty of Hoto Instruments regarding the products.

PRODUCTS EXPRESSLY NOT COVERED BY WARRANTY: Batteries, cables, attachments, adapters, and fixtures regardless of the manufacturer of the product, that are sold or provided for by Hoto Instruments are not covered by the foregoing warranties. Warranties of the respective manufacturers for such products shall apply.

DISCLAIMER OF OTHER WARRANTIES: Other than the foregoing warranties, there are no express or implied warranties or any affirmations of fact or promises by Hoto Instruments with respect to the products. Hoto Instruments disclaims any warranties, express, implied or statutory, not specifically set forth above. Without limiting the generality of the foregoing, Hoto Instruments expressly disclaims any implied warranties of merchantability, fitness for any particular purpose, infringement or any representations of fact or quality not expressly set forth herein.

LIMITATION OF LIABILITY AND REMEDIES: Hoto Instruments' sole responsibility and liability incurred as a result of the sale and/or use of the products, and the purchaser's exclusive remedy against Hoto Instruments under any warranty shall be limited to the repair or replacement, at Hoto Instruments' option, of product components not conforming to the warranty. The total liability of Hoto Instruments shall in no event exceed the amount actually paid to Hoto Instruments by purchaser with respect to the products. This limitation of remedy is intended by the parties to survive even if the remedy is claimed to have failed of its essential purpose. Purchaser's full and complete performance of all obligations of purchaser recited in this agreement is a condition precedent to Hoto Instruments' warranty obligations and liabilities herein.

PURCHASER'S DAMAGES AND LIMITATIONS: In no event shall Hoto Instruments be liable to purchaser, its assigns or agents, for economic loss, incidental or consequential damages, in contract or in tort, including but not limited to, any damages for lost profits, down-time, lost production, failure to meet purchaser's sales contracts, or defects in purchaser's materials or workmanship arising directly or indirectly from the use of the products. Hoto Instruments' limited warranty is terminated in the event of product overload, shock load, misuse, negligence, accident, or if repairs are attempted by the customer or third-parties without notice to and authorization by Hoto Instruments.

INSTRUCTIONS FOR OBTAINING WARRANTY REPAIR OR REPLACEMENT: Please contact our customer service department for a return authorization number. After you have obtained the authorization number, please return the subject product to Hoto Instruments with all freight, duty and brokerage costs prepaid. You will be notified by Hoto Instruments regarding the repair or replacement of the product. In some instances, Hoto Instruments may require proof of purchase.



ISO 9001 and ISO/IEC 17025 Accredited

3100 Dundee Road, Suite 707, Northbrook, IL 60062

1-866-527-4666 • Fax: 847-564-2095

www.hoto-instruments.com • E-mail: info@hoto-instruments.com

twilight

INSTRUMENTOS DE MEDICIÓN INDUSTRIAL



LLÁMANOS

+52(81) 8115-1400 / +52 (81) 8173-4300

LADA Sin Costo:
01 800 087 43 75

E-mail:
ventas@twilight.mx

www.twilight.mx



/ [twightsadecv](https://www.facebook.com/twightsadecv)



/ [twightsadecv](https://twitter.com/twightsadecv)



/ [twightsadecv](https://www.youtube.com/twightsadecv)